

**MM4Z Module User Guide**  
Revision 1.5

TABLE OF CONTENT .....	PAGE
1.0 PACKAGE AND CASE INFORMATION .....	4
1.1 PACKAGE OVERVIEW .....	4
1.2 LEDs AND PUSHBUTTONS .....	6
1.2.0 LEDs .....	6
1.2.1 Pushbuttons .....	6
1.3 TERMINAL BLOCKS .....	7
1.3.0 Terminal Block 1 (TB1) .....	7
1.3.1 Terminal Block 2 (TB2) .....	7
1.4 ETHERNET PORT .....	8
1.5 PROGRAMMING PORT .....	8
2.0 COMMUNICATION AND FUNCTION CODES .....	8
2.1 ETHERNET SEND/RECEIVE FORMAT .....	8
2.1.0 Ethernet Send Message Format .....	8
2.1.1 Ethernet Receive Message Format .....	9
2.2 RESPONSE CODES .....	9
2.3 FUNCTION CODE 03 .....	9
2.4 FUNCTION CODE 04 .....	9
2.5 FUNCTION CODE 05 .....	9
2.6 FUNCTION CODE 06 .....	9
2.7 FUNCTION CODE 0X10 .....	10
2.8 FUNCTION CODE 0X11 .....	10
3.0 MEMORY ORGANIZATION .....	11
3.1 RAM .....	11
3.1.0 Sensor/Module ID RAM space .....	11
3.1.1 Zone Count RAM space .....	12
3.1.2 Firmware Version / Unit ID Number RAM space .....	12
3.1.3 Sensor Count RAM space .....	12
3.1.4 Wheel Tracking RAM Memory Space .....	13
3.2 EVENT LOG MEMORY .....	13
3.3 SPECIAL MEMORY AREA USING FUNCTION CODE 0X10 .....	14
3.3.0 Writing Date/Time .....	14
3.4 FUNCTION CODE 0X05 .....	15
3.4.0 Supported Wheel Sensor Read parameters .....	15
3.4.1 Wheel Sensor Read Data Format .....	15
3.4.2 Function code 0x05 example .....	15
3.5 FUNCTION CODE 0X06 .....	16
3.5.0 Supported Wheel Sensor Write parameters .....	16
3.5.1 Wheel Sensor Write Data Format .....	16
3.5.2 Function Code 0x06 Example .....	16
3.6 FUNCTION CODE 0X11 .....	16
3.6.1 Remote Zone Reset .....	17
4.0 MODULE MODES AND FUNCTIONS .....	17
4.1 PROGRAM MODE .....	17
4.2 RUN MODE .....	17
4.2.0 Run Mode Wait .....	18
4.2.1 Run Mode Polling .....	18
5.0 MODULE FUNCTIONS .....	19
5.1 AUTO-LINE .....	19
5.2 WHEEL COMPENSATION .....	19
5.3 WHEEL TRACKING .....	20

5.4 INPUT LOGGING .....	20
6.0 EVENT LOG .....	21
6.1 EVENT LOG DATA POINTER .....	21
6.2 EVENT LOG PAGING.....	21
6.2.0 Reading Single Event from Event Log Example.....	21
6.3 EVENT FORMATS .....	23
6.2.0 Event Descriptions.....	25
7.0 MMZ MODULE PROGRAMMER PC SOFTWARE.....	30
7.1 ZONES TAB .....	30
7.1.1 Adding/Removing sensors to a Zone.....	30
7.1.2 Configuring sensor for “Count Down” direction .....	31
7.1.3 Reading/Writing Zones .....	31
7.2 EVENT LOG TAB .....	31
7.3 MONITOR TAB.....	31
7.4 MODULE TAB.....	32
7.4.0 Searching Network for connected Modules.....	32
7.4.1 Edit Device Details Tab .....	34
7.4.2 Read Network Configuration Tab .....	34
7.5 WHEEL SENSOR TAB .....	34
7.5.0 Port Type .....	34
7.5.1 Auto-Detect.....	35
7.5.2 Scan/Diagnose.....	35
7.5.3 Read ID.....	35
7.5.4 Send ID .....	35
7.5.5 Read Coil .....	35
7.5.6 Send Coil .....	35
7.6 ETHERNET CONFIGURATION MENU.....	36
7.6.0 Module IPs Tab.....	36
7.6.1 Network Adapters Tab .....	36
7.7 SELECTING AN IP ADDRESS FOR COMMUNICATION .....	37
7.8 SERIAL MENU.....	37
7.8.0 COM Ports .....	37
7.8.2 Upgrade Firmware .....	37
ANNEX A. REVISION HISTORY.....	42
A.1 REVISION 1.0 .....	42
A.2 REVISION 1.1 .....	42
A.3 REVISION 1.2 .....	42
A.4 REVISION 1.2.1 .....	42
A.5 REVISION 1.2.2 .....	42
A.6 REVISION 1.3 .....	42
A.7 REVISION 1.4 .....	42
A.8 REVISION 1.5 .....	42

## 1.0 Package and Case Information

### 1.1 Package Overview




Figure 1-0 Package top view




Figure 1-1 Package side view





Figure 1-2 Package side view











**Figure 1-3 Module/Wheel Sensor Connection Overview**

## 1.2 LEDs and Pushbuttons









### 1.2.0 LEDs

LEDs are grouped into two separate LED strips. LEDS1 indicate input pins, while LEDS2 indicate output pins.

**Table 1-0 LEDS1 Definition**

Input Indicators (LEDS1)	LEDS1  TB1 - 1  TB1 - 2  TB1 - 3  TB1 - 4  TB1 - 5  TB1 - 6  TB1 - 7  TB1 - 8	Position	Description	Definition
		<b>Figure 1-4 LEDS1 (Input Indicators)</b>	LED8	Terminal Block 1 Pin 1
LED7	Terminal Block 1 Pin 2		On – Power applied to pin Off – Power not applied to pin	
LED6	Terminal Block 1 Pin 3		On – Power applied to pin Off – Power not applied to pin	
LED5	Terminal Block 1 Pin 4		On – Power applied to pin Off – Power not applied to pin	
LED4	Terminal Block 1 Pin 5		On – Power applied to pin Off – Power not applied to pin	
LED3	Terminal Block 1 Pin 6		On – Power applied to pin Off – Power not applied to pin	
LED2	Terminal Block 1 Pin 7		On – Power applied to pin Off – Power not applied to pin	
LED1	Terminal Block 1 Pin 8		On – Power applied to pin Off – Power not applied to pin	

**Table1-1 LEDS2 Definition**

Output Indicators (LEDS2)	LEDS2  TB2 - 1  TB2 - 2  TB2 - 3  TB2 - 4  TB2 - 5  TB2 - 6  TB2 - 7  TB2 - 8	Position	Description	Definition
		<b>Figure 1-5 LEDS2 (Output Indicators)</b>	LED8	Run Mode Active
LED7	Auto Line Normal		On – Auto Line Normal in progress Off – Auto Line Normal not in progress	
LED6	Auto Line Reverse		On – Auto Line Reverse in progress Off – Auto Line Reverse not in progress	
LED5	Zone Fault		On – Zone fault has occurred Off – Zone fault has not occurred	
LED4	Zone 4 Status		On – Zone Not Occupied Off – Zone Occupied	
LED3	Zone 3 Status		On – Zone not Occupied Off – Zone Occupied	
LED2	Zone 2 Status		On – Zone Not Occupied Off - Zone Occupied	
LED1	Zone 1 Status		On – Zone Not Occupied Off – Zone Occupied	

### 1.2.1 Pushbuttons

Four pushbuttons are provided for individual zone resets. Pushbuttons have three functions.

Function 1: During Run Mode Wait Sequence (See section 4.2.0), Pushbuttons are used to activate individual zones and enter Run Mode Polling Sequence (See Section 4.2.1). Pushbutton must stay depressed for at least 300 milliseconds to activate zone.

Function 2: After a zone is already activated, pushbuttons are used to reset individual Zones. Pushbutton must stay depressed for at least 300 milliseconds to reset Zone.

Function 3: If Zone 1 and Zone 2 pushbuttons are held down at power up, default network configuration will be applied to the MM4Z Ethernet port (IP = 192.168.1.8, Gateway = 192.168.1.1, 8 host bits). The Module will acknowledge the configuration change by flashing the Run light. This procedure only applies to Firmware version 1.23 and above.

### 1.3 Terminal blocks

#### 1.3.0 Terminal Block 1 (TB1)

Table 1-2 Terminal Block 1 Pinout

Inputs (TB1)	TB1		Pin	Description	Definition
	Not Used	1	1	Not Used	
	Not Used	2	2	Not Used	
	Not Used	3	3	Not Used	
	Not Used	4	4	Not Used	
	Not Used	5	5	Not Used	
	Not Used	6	6	Not Used	
	External Reset	7	7	External Reset	Pulled High to reset
	Program/Run Mode Select	8	8	Program/Run Mode Select	Pulled High at power up - Enter program mode Else, - Enter run mode
	Inputs Ground Pin	9	9	Input Pins Ground Input	Ground reference for input pins
Power Input Ground	10	10	Power Input Ground	Ground reference for MM4Z Module	


#### 1.3.1 Terminal Block 2 (TB2)

Table 1-3 Terminal Block 2 Pinout

Outputs (TB2)	TB2		Pin	Description	Definition
	Run Mode Active	1	1	Run Mode active	High – Run Mode Active Low - Run Mode Not Active
	Auto Line Normal	2	2	Auto Line Normal	High – Auto Line Normal in progress Low – Auto Line Normal Not in progress
	Auto Line Reverse	3	3	Auto Line Reverse	High – Auto Line Reverse in progress Low – Auto Line Reverse Not in progress
	Zone 4 Occupied / Not Occupied	4	4	Zone Fault	High – Zone Fault Occurred Low – No Zone Fault Occurred
	Zone 3 Occupied / Not Occupied	5	5	Zone 4 Occupied/Not Occupied	High – Zone Unoccupied Low – Zone Occupied
	Zone 2 Occupied / Not Occupied	6	6	Zone 3 Occupied/Not Occupied	High – Zone Unoccupied Low – Zone Occupied
	Zone 1 Occupied / Not Occupied	7	7	Zone 2 Occupied/Not Occupied	High – Zone Unoccupied Low – Zone Occupied
	Outputs Power Input	8	8	Zone 1 Occupied/No Occupied	High – Zone Unoccupied Low – Zone Occupied
	Power input +12V	9	9	Output Pins +V reference	+V reference for output pins. Output Pins 1-8 will be pulled up +V reference when asserted High
	10	10	Power Input +12V	Power input for MM4Z Module	


## 1.4 Ethernet Port

**Table 1-4 Ethernet Port**

<b>Ethernet Port</b>	 <p>Figure 1-8 Ethernet Port Front View</p>	Ethernet Network Interface			
	<b>LED1</b>		<b>LED2</b>		
	<b>Color</b>	<b>Meaning</b>	<b>Color</b>	<b>Meaning</b>	
	Off	No Link	Off	No Activity	
	Amber	10 Mbps	Amber	Half-Duplex	
	Green	Green	Full-Duplex		

## 1.5 Programming port

**Table 1-5 Programming Port**

<b>Programming Input TB4</b>	 <p>Figure 1 - 9 Programming Port</p>	<b>Pin</b>	<b>Description</b>	<b>Definition</b>
		1	Data Terminal Ready	
		2	Transmit Data	Data Transmitted by the Module
		3	Receive Data	Data Received by the Module
		4	Signal Ground	Ground Reference for Rec./Trans. Data
		5	Signal Ground	Ground Reference for Rec./Trans. Data

## 2.0 Communication and Function Codes

When communicating with the MM4Z Module, Module ID 0xFF is used as a universal address. All connected Modules will answer to Module ID 0xFF.

### 2.1 Ethernet Send/Receive Format

#### 2.1.0 Ethernet Send Message Format

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Memory Address (2 Bytes)		# Bytes Requested (2 Bytes)		# Data Bytes
Hi Byte	Lo Byte	Hi Byte	Lo Byte	Hi Byte	Lo Byte			Lo Byte	Hi Byte	Lo Byte	Hi Byte	

Transaction identifier – Identifier of Request/Response transaction  
 (Transaction identifier copied from request to response message)

Protocol Identifier - always 0000

Message length – Number of bytes to follow

Unit identifier – Module ID Number

Function Code –Function Code

Memory Address – Start Address to Read/Write

# Bytes Requested – Number of Bytes to Read/Write

# Data Bytes – Data Bytes



### 2.1.1 Ethernet Receive Message Format

Transaction ID (2 Bytes)		Protocol ID (2 Bytes)		Message Length (2 Bytes)		Unit ID	Function Code	# Data Bytes (2 Bytes)		# Data Bytes
Hi Byte	Lo Byte	Hi Byte	Lo Byte	Hi Byte	Lo Byte			Hi Byte	Lo Byte	

Transaction identifier – Identifier of Request/Response transaction.

Transaction identifier copied from request to response message.

Protocol Identifier - always 0000

Message length – Number of bytes to follow

Unit identifier – Module ID Number

Function Code –Function Code

# Bytes Requested – Number of Bytes to Read/Write

# Data Bytes – Data Bytes

### 2.2 Response Codes

**Table 2-0 Response Codes**

Exception Code	Definition
0x01	Operation Successful
0x02	Operation Unsuccessful
0x05	Improper number of bytes
0xFC	Protected Memory Address
0xFE	Operation prohibited during Run Mode Polling Sequence (See Section 4.2.1)
0xFF	CRC Error

### 2.3 Function Code 03

Function Code 03 is used to read RAM Locations (See Section 3.1). Up to 256 bytes can be read at a time

### 2.4 Function Code 04

Function Code 04 is used to read Event Log memory locations (See Section 3.2). Up to 128 bytes can be read at a time.

### 2.5 Function Code 05

Function Code 05 is used to read wheel sensor parameters through MM4Z hardware.

### 2.6 Function Code 06

Function Code 06 is used to write wheel sensor parameters through MM4Z hardware.

### **2.7 Function Code 0x10**

Function Code 0x10 is used to write Sensor ID / Module ID information to RAM memory space.

Function code 0x10 can only be used while MM4Z Module is in Run Mode Wait state (See Section 4.2.0). If attempting to use Function Code 0x10 while Module is in Polling Mode (See Section 4.2.1), Module will return Response Code 0xFE (Operation prohibited during Run Mode Polling Sequence).

### **2.8 Function Code 0x11**

Function Code 0x11 is used to execute remote functions. See section 3.6

### 3.0 Memory Organization

#### 3.1 RAM

RAM locations are read using function code 03. RAM data space occupies memory locations 0xF000 to 0xF5FF. Up to 256 data bytes of RAM can be read at a time.

##### 3.1.0 Sensor/Module ID RAM space

Module/Sensor ID RAM locations range from 0xF000 – 0xF0FF

**Table 3-0 Sensor ID RAM Locations**

Memory Location	Definition	Memory Location	Definition
0xF000 - 0xF003	Zone 1 Sensor / Module 1	0xF080 - 0xF083	Zone 3 Sensor / Module 1
0xF004 - 0xF007	Zone 1 Sensor / Module 2	:	Zone 3 Sensor / Module 2
0xF008 - 0xF00B	Zone 1 Sensor / Module 3	:	Zone 3 Sensor / Module 3
0xF00C - 0xF00F	Zone 1 Sensor / Module 4	:	Zone 3 Sensor / Module 4
0xF010 - 0xF013	Zone 1 Sensor / Module 5	:	Zone 3 Sensor / Module 5
0xF014 - 0xF017	Zone 1 Sensor / Module 6	:	Zone 3 Sensor / Module 6
0xF018 - 0xF01B	Zone 1 Sensor / Module 7	:	Zone 3 Sensor / Module 7
0xF01C - 0xF01F	Zone 1 Sensor / Module 8	:	Zone 3 Sensor / Module 8
0xF020 - 0xF023	Zone 1 Sensor / Module 9	:	Zone 3 Sensor / Module 9
0xF024 - 0xF027	Zone 1 Sensor / Module 10	:	Zone 3 Sensor / Module 10
0xF028 - 0xF02B	Zone 1 Sensor / Module 11	:	Zone 3 Sensor / Module 11
0xF02C - 0xF02F	Zone 1 Sensor / Module 12	:	Zone 3 Sensor / Module 12
0xF030 - 0xF033	Zone 1 Sensor / Module 13	:	Zone 3 Sensor / Module 13
0xF034 - 0xF037	Zone 1 Sensor / Module 14	:	Zone 3 Sensor / Module 14
0xF038 - 0xF03B	Zone 1 Sensor / Module 15	:	Zone 3 Sensor / Module 15
0xF03C - 0xF03F	Zone 1 Sensor / Module 16	0xF0BC - 0xF0BF	Zone 3 Sensor / Module 16
0xF040 - 0xF043	Zone 2 Sensor / Module 1	0xF0C0 - 0xF0C3	Zone 4 Sensor / Module 1
:	Zone 2 Sensor / Module 2	:	Zone 4 Sensor / Module 2
:	Zone 2 Sensor / Module 3	:	Zone 4 Sensor / Module 3
:	Zone 2 Sensor / Module 4	:	Zone 4 Sensor / Module 4
:	Zone 2 Sensor / Module 5	:	Zone 4 Sensor / Module 5
:	Zone 2 Sensor / Module 6	:	Zone 4 Sensor / Module 6
:	Zone 2 Sensor / Module 7	:	Zone 4 Sensor / Module 7
:	Zone 2 Sensor / Module 8	:	Zone 4 Sensor / Module 8
:	Zone 2 Sensor / Module 9	:	Zone 4 Sensor / Module 9
:	Zone 2 Sensor / Module 10	:	Zone 4 Sensor / Module 10
:	Zone 2 Sensor / Module 11	:	Zone 4 Sensor / Module 11
:	Zone 2 Sensor / Module 12	:	Zone 4 Sensor / Module 12
:	Zone 2 Sensor / Module 13	:	Zone 4 Sensor / Module 13
:	Zone 2 Sensor / Module 14	:	Zone 4 Sensor / Module 14
:	Zone 2 Sensor / Module 15	:	Zone 4 Sensor / Module 15
	Zone 2 Sensor / Module 16	0xF0FC - 0xF0FF	Zone 4 Sensor / Module 16

**Table 3-1 Sensor ID Byte Field**

Location	0xF000	0xF001	0xF002	0xF003
Definition	Bit Field (See Table 3-2)	Undefined	Module ID	Sensor ID

**Table 3-2 Sensor ID Bit Field**

Bits	Description	
7:0	Bit 7	1 – Count Down
		0 – Count Up
	Bit 6	1 – Auto Line Enabled
		0 – Auto Line Disabled
	Bit 5	1 – Auto Line Reverse
		0 – Auto Line Normal
	Bit 4 - Undefined	
	Bit 3 - Undefined	
	Bit 2 - Undefined	
	Bit 1 - Undefined	
Bit 0 - Undefined		

### 3.1.1 Zone Count RAM space

Zone count RAM locations range from 0xF100 – 0xF10F

Zone counts can only be read if start address of query is 0xF100 – 0xF10F

**Table 3-3 Zone Count RAM space**

Memory Location	Definition
0xF100 - 0xF103	Zone 1 Current Count
0xF104 - 0xF107	Zone 2 Current Count
0xF108 - 0xF10B	Zone 3 Current Count
0xF10C - 0xF10F	Zone 4 Current Count

### 3.1.2 Firmware Version / Unit ID Number RAM space

**Table 3-4 Firmware version / Unit ID number memory locations**

Parameter	Address
Firmware Version (Integer Portion)	0xF37D
Firmware Version (Fraction Portion)	0xF37E
Unit ID	0xF37F

### 3.1.3 Sensor Count RAM space

Sensor Count RAM locations range from 0xF380 – 0xF3FF

Each Sensor Count is 2 Bytes.

**Table 3-5 Sensor Count RAM Locations**

Memory Location	Definition	Memory Location	Definition
0xF380 - 0xF39F	Zone 1 Sensor Counts	0xF3C0 - 0xF3DF	Zone 3 Sensor Counts
0xF3A0 - 0xF3BF	Zone 2 Sensor Counts	0xF3E0 - 0xF3FF	Zone 4 Sensor Counts

**Table 3-6 Sensor Count Byte Field**

<b>0xF380</b>	<b>0xF381</b>
MSB	LSB

**3.1.4 Wheel Tracking RAM Memory Space**

Wheel tracking RAM space ranges from memory locations 0xF50F – 0xF58E  
 Positive Wheel Counts (Wheels In) memory space range from 0xF50F – 0xF54E

Negative Wheel Counts (Wheels Out) memory space range from 0xF54F – 0xF58E

Each Wheel Sensor Wheel Tracking Count register is 4 bytes long

Each Zone tracks 4 individual sensors

**Table 3-7 Wheel Tracking Memory Locations**


Location	Definition	Location	Definition
0xF50F – 0xF51E	Wheels In: Zone 1	0xF54F – 0xF55E	Wheels Out: Zone 1
0xF51F – 0xF52E	Wheels In: Zone 2	0xF55F – 0xF56E	Wheels Out: Zone 2
0xF52F – 0xF53E	Wheels In: Zone 3	0xF56F – 0xF57E	Wheels Out: Zone 3
0xF53F – 0xF54E	Wheels In: Zone 4	0xF57F – 0xF58E	Wheels Out: Zone 4

**3.2 Event Log Memory**

Event log is read using function code 04.

Event log is split into two separate “pages” (Page1: 0x0000 – 0xFFFF, Page2: 0x10000 – 0x1FFFF) See section 6.2 for explanation of event log paging.

Up to 128 data bytes of event log can be read at a time.



**Figure 3-1 Event Log Memory Map**

**Table 3-8 Event Log Locations**

Location	Definition
0x01FD	Event Log Page
0x01FE	Event Log Address Hi Byte
0x01FF	Event Log Address Lo Byte
0x0200 - 0x1FFFF	Event Log

### 3.3 Special Memory Area Using Function Code 0x10

Function code 0x10 can only be used while module is in run mode wait sequence (See Section 4.2.0).

#### 3.3.0 Writing Date/Time

Date/Time can be edited by writing 7 bytes to memory location 0x200.

Date/Time can be edited in both wait mode and polling mode in Firmware versions 1.23 and above.

#### Writing Date/Time Example

If the current date was: 01-June-2011 (01-06-2011)

And the current time was: 3:20:43 PM = 15:20:43 (24 hour format)

**Table 3-9. Date/Time Data Byte Field**

Byte	0	1	2	3	4	5	6
Definition	Seconds	Minutes	Hour (24 hour format)	Not Used	Day	Month	Year (last two digits)

Using Table 3-9,

Data byte string = 0x2B 0x14 0x0F 0x00 0x01 0x06 0x0B

**Table 3-10. Ethernet Send Message Format**

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Memory Address (2 Bytes)		# Bytes Requested (2 Bytes)		Data byte string
0x00	0x01	0x00	0x00	0x00	0x0D	0xFF	0x10	0x02	0x00	0x00	0x07	Data byte string

Upon successful writing of Date/Time parameters, Module will acknowledge by sending a single return byte 0x01 (Operation Successful)

### 3.4 Function code 0x05

Function code 0x05 is used to read Wheel Sensor parameters over Ethernet or RS485 interface.

#### 3.4.0 Supported Wheel Sensor Read parameters

**Table 3-11 Supported Wheel Sensor Read Parameters**

Address (Hex)	Parameter	Return Format	
		Hi Byte	Lo Byte
00	Coil #1 (+) Threshold	xx	00-FF
01	Coil #1 (1) Threshold	xx	00-FF
02	Coil #2 (+) Threshold	xx	00-FF
03	Coil #2 (-) Threshold	xx	00-FF
04	Sensitivity	Coil #1	Coil #2
05	Baseline	Coil #1	Coil #2
AA	Analog Value Coil #1	xx	00-FF
A5	Analog Value Coil #2	xx	00-FF
AD	Counter Contents	00-FF	00-FF
D5	ID Number	xx	00-1F

#### 3.4.1 Wheel Sensor Read Data Format

**Table 3-12 Standard Serial Wheel Sensor Request Data Format**

STX (fixed)	Sensor ID	Parameter	ETX (fixed)
02	xx	See table 3-11	03

#### 3.4.2 Function code 0x05 example

Ethernet communication follows the format outlined in **Section 2.0**. **Four data bytes are sent in request.**

**Table 3-13 Read From Wheel Sensor Over Ethernet Request Example**

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	STX	Sensor ID Number	Parameter	ETX
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x05	0x02	xx	See Table 3-11	0x03

**Table 3-14 Read From Wheel Sensor Over Ethernet Response Example**

Transaction ID (2 Bytes)		Protocol ID (2 Bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Parameter (Echoed from request)	Data (2 bytes)		ETX
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x5	See Table 3-11	Hi byte	Lo byte	0x03

### 3.5 Function Code 0x06

#### 3.5.0 Supported Wheel Sensor Write parameters

**Table 3-15 Supported Wheel Sensor Write Parameters**

Address (Hex)	Parameter	Return Format	
		Hi Byte	Lo Byte
00	Coil #1 (+) Threshold	xx	00-FF
01	Coil #1 (1) Threshold	xx	00-FF
02	Coil #2 (+) Threshold	xx	00-FF
03	Coil #2 (-) Threshold	xx	00-FF
AD	Counter Contents	00-FF	00-FF
D5	Id Number	xx	00-1F

#### 3.5.1 Wheel Sensor Write Data Format

**Table 3-16 Standard Wheel Sensor Send Data Format**

STX (fixed)	Sensor ID	Parameter	0x2E (fixed)	Data (2 Bytes)	ETX (fixed)
02	xx	See table 3-15	0x2E		03

#### 3.5.2 Function Code 0x06 Example

**Table 3-17 Write to Wheel Sensor Over Ethernet Request Example**

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Sensor ID	Parameter	Data (2 Bytes)	
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x06	xx	See Table 3-15	Hi byte	Lo byte

**Table 3-18 Write to Wheel Sensor Over Ethernet Response Example**

Transaction ID (2 Bytes)		Protocol ID (2 Bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Parameter (Echoed from request)	Data (2 bytes)		ETX
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x06	See Table 3-15	Hi byte	Lo byte	0x03

### 3.6 Function Code 0x11

Function code 0x11 is used to execute special functions.

**Table 3-19 Function Addresses**

Address	Function	Definition
0x0000	Remote Sensor Reset	See Section 3.6.1
0x0001	Remote Zone Reset	See Section 3.6.2



### 3.6.0 Remote Sensor Reset

**Table 3-20 Remote Sensor Reset Ethernet Request Format**

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Address Hi	Address Lo	Data (2 Bytes)	
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x11	0x00	0x00	0x00	Sensor ID #

### 3.6.1 Remote Zone Reset

**Table 3-21 Remote Zone Reset Request Format**

Transaction ID (2 Bytes)		Protocol ID (2 bytes)		Message Length (2 Bytes)		Unit ID	Function Code	Address Hi	Address Lo	Data (2 Bytes)	
0x00	0x01	0x00	0x00	0x00	0x06	0xFF	0x11	0x00	0x01	0x00	See Table 3-22

**Table 3-22 Zone Reset bitfield**

b7	b6	b5	b4	b3	b2	b1	b0
x	x	x	x	Reset Zone 4	Reset Zone 3	Reset Zone 2	Reset Zone 1

## 4.0 Module Modes and Functions

### 4.1 Program Mode

Program Mode is used to upgrade device firmware.

To enter Program Mode, pin 8 of Terminal Block 1 is pulled high during power up.

While in Programming Mode, the “Update Firmware” option of the MM4Z Module Programmer PC software can be used to update the MM4Z Module firmware (See Section 7.8.2).

To exit Program Mode, the MM4Z Module must be powered up with pin 8 of Terminal Block 1 pulled LOW or left unconnected.

### 4.2 Run Mode

Run Mode is used while executing normal Module functions (i.e. maintaining Zone/Sensor counts)

Run Mode is entered when pin 8 of Terminal Block 1 is pulled low, or left unconnected during module power up.

Entrance into Run mode is verified when LED1 of LEDS2 is on.

#### **4.2.0 Run Mode Wait**

Upon entering Run Mode, Module will wait for zone activation. Zone activation is performed in one of two ways.

##### **a. Using Zone Reset Pushbuttons**

Depressing any of the four Zone Reset Pushbuttons for at least 300 milliseconds will activate its corresponding zone and send the MM4Z Module into the polling mode (See Section 4.2.1)

##### **b. Using External Reset**

External reset is provided on TB1 Pin 7. Pulling External Reset up (+12V) for at least 300 milliseconds will activate reset once TB1 Pin 7 returns LOW.

**Upon external reset, the Module will reset / activate all four zones and enter Run Mode Polling.**

While Module is in Run Mode Wait Sequence, writing of Sensor ID/Module ID information using Function Code 0x10 is permitted, and the full event log can be read out of event log memory space.

As soon as any zone is activated, Module immediately enters Run Mode Polling Sequence.

#### **4.2.1 Run Mode Polling**

When in Run Mode Polling Sequence, all activated Zones will be polled and zone counts will be maintained.

## 5.0 Module Functions


### 5.1 Auto-Line

Auto-line function is used to provide an auto-line pulse on either of the two auto-line outputs (TB2 -1 Auto-Line Normal, TB2-2 Auto-Line Reverse).

Auto-line can be configured on any of the sixteen sensors in zone one.

Auto-Line can only be triggered when a Wheel Sensor configured for auto-line causes the total zone count to increase from zero to a positive number.

Auto-line will not trigger until one wheel has completely passed over the Wheel Sensor configured for auto-line.



**Figure 5.0 Auto line pulse diagram**

### 5.2 Wheel Compensation

The main function of wheel compensation is to compensate for dragging hoses and hanging chains that might cause a single undesirable count. See D.2 for Wheel Compensation Flow Diagram.

Wheel Compensation has three configurable options

- a) Enabled  
Compensation will occur for +1/-1 zone count
- b) Disabled  
Compensation will never trigger
- c) Enabled only for -1 count  
Compensation will occur only for -1 zone count

### **5.3 Wheel Tracking**

Wheel tracking will keep count of wheels entering a zone and wheels leaving a zone for the first four configured sensors in each zone.

Wheel tracking event will be written to the event log when the total zone count returns to zero, when a fault occurs, when a wheel compensation event occurs, or when a zone reset occurs on a previously enabled zone.

See section 3.1.4 for Wheel Tracking RAM Memory Space

### **5.4 Input Logging**

Inputs 1 – Inputs 6 are available for input logging. If Input state changes and holds for at least 250 milliseconds, event 0x000F will be written to the event log recording the current state of the changed input.

## 6.0 Event Log

The Event Log occupies memory locations 0x0200 – 0x1FFFF (See Section 3.2). Each event is comprised of 16 Bytes. Event log can store up to 8160 events at a time.

### 6.1 Event Log Data Pointer

The event log data pointer is 3 bytes occupying event log memory locations 0x01FD – 0x01FF. Event log data pointer always points to the next memory location to be filled by an event.

After writing an event to memory location 0x1FFF0, event log data pointer will rollover and point at memory location 0x0200

**Table 6-0 Event Log Data Pointer Byte Field**

Location	Definition
0x01FD	Event Log Page
0x01FE	Event Log Address Hi Byte
0x01FF	Event Log Address Lo Byte

Location 0x01FD (Event Log Page) indicates event log memory “page”. See Section 6.2 for explanation of event log paging.

### 6.2 Event Log Paging

The Hi Byte on “number of registers requested” block of the Ethernet TCP Send message is used to specify the event log page to read.

Ethernet TCP Send Message to read Page 1 Address 0x01FD.

```
0001 0000 0006 30 04 01FD 0003
                        ↑
                    Hi Byte (Read Page 1)
```

Ethernet TCP Send Message to read Page 2 Address 0x01FD.

```
0001 0000 0006 30 04 01FD 0103
                        ↑
                    Hi Byte (Read Page 2)
```

#### 6.2.0 Reading Single Event from Event Log Example

##### Step 1: Reading the Event Log Data Pointer

The Event Log Data Pointer always points to the next memory address to be filled by an incoming event.

Ethernet TCP Send Message:

0001 0000 0006 30 04 01FD 0003

Ethernet TCP Return Message:

0001 0000 0007 30 04 0003 **00 02 10**

**00 02 10** is the Event Log data pointer

**00** – Current Event Log “page”

**02** – Event Log Address Hi Byte

**10** – Event Log Address Lo Byte

### **Step 2: Read the Log**

Ethernet TCP Send Message:

0001 0000 0006 30 04 0200 0010

Ethernet TCP Return Message:

0001 0000 0014 30 04 0010 **00 01 39 15 10 01 12 10 25 00 00 00 01  
12 FF FF**

From the above Return Message and the information in Section 6.3, the returned event would be:

Event: Power Up Event

Date: 12/01/2010

Time: 10:15:39

Temp: 25 °C

Inputs: 0x00

Outputs: 0x00

Event Specific Information: Firmware Version 1.18

### 6.3 Event Formats

**Table 6-1 Standard Event Format**

Byte	Description
1	Event Code Hi Byte
2	Event Code Lo Byte
3	Seconds
4	Minutes
5	Hour
6	Date
7	Month
8	Year
9	Temp MSB
10	Temp LSB
11	Inputs
12	Outputs
13	Event Specific Byte 1
14	Event Specific Byte 2
15	Event Specific Byte 3
16	Event Specific Byte 4

**Table 6-2 Event Log Inputs bit Field**

Inputs	Bit 7 MSb	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 LSb
	TB1-1	TB1-2	TB1-3	TB1-4	TB1-5	TB1-6	TB1-7	TB1-8

1 –Input/Output state high

0 –Input/Output state low or floating

**Table 6-3 Event Log Outputs bit Field**

Outputs	Bit 7 MSb	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 LSb
	TB2-1	TB2-2	TB2-3	TB2-4	TB2-5	TB2-6	TB2-7	TB2-8

**Table 6-4 Event Time/Date/Temp bit Field**

Field	Bit 7 MSb	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0 LSb	Range
Seconds	0	10 Seconds			Seconds				0x00 – 0x59
Minutes	0	10 Minutes			Minutes				0x00 – 0x59
Hour	0	0	10 Hour	10 Hour	Hour				0x00 – 0x23
Date	0	0	10 Date		Date				0x01 – 0x31
Month	Century	0	0	10 Month	Month				0x01 – 0x12 + Century
Year	10 Year				Year				0x00 – 0x99
Temp MSB	Sign	Data	Data	Data	Data	Data	Data	Data	-
Temp LSB	Data	Data	0	0	0	0	0	0	-

 - Denotes fixed value

Hour Register is read / written in 24hour format  
Century bit is set when year rolls over from 99 to 00

Actual Year = (2000 + (100 \* Century bit)) + Year count register.  
For example, if year count register equals 10 and century bit is not set, then actual year equals 2010

Temperature is represented by a 10 bit code. The lower 7 bits of the Temp MSB register represent the integer value of the current temperature. The MSb of the Temp MSB register represents the temperature sign (0 – Positive, 1 – Negative). The upper 2 bits of the Temp LSB register represent the fraction portion of the current temperature with a resolution of 0.25°C (0x00 – 0.00°C, 0x40 – 0.25°C, 0x80 = 0.50°C, 0xC0 – 0.75°C).  
For example, 0x30 in the Temp MSB register and 0x40 in the Temp LSB register would represent 30.25°C.

**Table 6-5 Baseline Fault bit field**

Bit	7	6	5	4	3	2	1	0
<b>Definition</b>	Coil #1 Sensitivity	Coil #2 Sensitivity	Analog Value Coil #1	Analog Value Coil #2	Analog Value - Baseline #1	Analog Value - Baseline #2	Not Used	Sensor Unresponsive

**Table 6-6 Module bit field**

Bit	7	6	5	4	3	2	1	0
<b>Definition</b>	1 - Wheel Compensation Enabled	1 – Allow Reset After Fault = True	1 – Allow only -1 Count Compensation	Not Used	Not Used	Not Used	Not Used	Not Used
	0 – Wheel Compensation Disabled	0 – Allow Reset After Fault = False	0 – Allow both +/- 1 Count Compensation					

**Table 6-7 Non standard Event Format**

Event ID	0x8012	0x0009	0x0030
Byte	Description	Description	Description
1	Event Code Hi Byte	Event Code Hi Byte	Event Code Hi Byte
2	Event Code Lo Byte	Event Code Lo Byte	Event Code Lo Byte
3	Zone Number	Seconds	Zone Number
4	Sensor ID	Minutes	Bit Field
5	Coil #1 Sensitivity	Hour	Undefined
6	Coil #2 Sensitivity	Date	Module ID
7	Coil #1 Baseline	Month	Sensor ID
8	Coil #2 Baseline	Year	Wheels In Hi Byte
9	Coil #1 Analog	Inputs	Wheels In Byte 1
10	Coil #2 Analog	Outputs	Wheels In Byte 2
11	Counter Hi Byte	Seconds (changed to)	Wheels in Byte 3
12	Counter Lo Byte	Minutes (changed to)	Wheels Out Hi Byte
13	Wheel Sensor Bit Field (See Table 3-2)	Hour (changed to)	Wheels Out Byte 1
14	Baseline Fault Bit Field (See Table 6-5)	Date (changed to)	Wheels Out Byte 2
15	Not used	Month (changed to)	Wheels Out Byte 3
16	Not used	Year (changed to)	Not Used



## 6.2.0 Event Descriptions

### Event ID: 0x0000

#### Definition: PC/Module Date/Time

**Description:** This event does not actually exist in the event log memory space of the MM4Z Module. It reads the current PC and Module date time when event log memory space is read

### Event ID: 0x0001

#### Definition: Power Up

**Description:** Written to log after initial power up delay

**Event Specific Bytes:** Byte 1 – Firmware Version Integer portion  
Byte 2 – Firmware Version Fraction portion

### Event ID: 0x0002

#### Definition: External Reset

**Description:** Written to the log after external reset pin has returned low after being pulled up for at least 250 milliseconds.

**Event Specific Bytes:** Byte 1 – Firmware Version Integer portion  
Byte 2 – Firmware Version Fraction portion

### Event ID: 0x0004

#### Definition: Count Up from Zero

**Description:** Written to the event log when the total zone count goes from a count of zero to a positive number. Corresponding zone will show occupied status before this event is written to the log. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the previous count in the corresponding Wheel Sensor (initial count before total zone count increased from zero)

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

### Event ID: 0x0005

#### Definition: Count Down to Zero

**Description:** Written to the event log when the total zone count decreases from a positive count down to zero. This event is written after the corresponding zone output shows unoccupied status. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the current count in the corresponding Wheel Sensor (the count in the Wheel Sensor that caused the total zone count to return to zero)

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x0006**

**Definition:** Zone Reset

**Description:** Written to the event log after a zone reset pushbutton has been released after being depressed for at least 300 milliseconds. This event is written to the event log prior to the corresponding zone output showing unoccupied status.

**Event Specific Bytes:** Byte 1 – Zone Number

**Event ID: 0x0007**

**Definition:** Unresponsive Sensor

**Description:** Written to the log after a Wheel Sensor is found to be unresponsive either from framing errors, unresponsive retries, or a combination of the two.

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID

**Event ID: 0x0008**

**Definition:** Wheel Compensation

**Description:** Written to the log after the programmed wheel compensation time has elapsed. This event will be written after the total zone count has been reset to zero, but before the corresponding zone output shows unoccupied status.

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Programmed Wheel Compensation Time Hi Byte  
Byte 4 – Programmed Wheel Compensation Time Lo Byte

$C_{Total} = \text{Wheel Compensation Time (Seconds)}$

$C_{Total} = ((\text{Byte 3} * 256) + \text{Byte 4}) * 0.005$

**Event ID: 0x0009**

**Definition:** Date/Time Change

**Description:** Written to the log after a new date/time is written to the Module. This event does not conform to the standard event log format (See Table 6-7).

**Event ID: 0x000A**

**Definition:** Negative Count Limit Exceeded

**Description:** Written to the log after the total zone count decreases to or below -2 (Zone Count Register  $\leq 0xFFFFFFFF8$ )

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x000B**

**Definition:** Auto-Line

**Description:** Written to the log after auto-line occurs

**Event Specific Bytes:** Byte 1 – Sensor ID that triggered auto-line  
Byte 2 – Sensor bit field (See Table 3-2)

**Event ID: 0x000D**

**Definition:** New Wheel Compensation Time

**Description:** Written to the log after a new wheel compensation time is configured

**Event Specific Bytes:** Byte 1 – Previous Time Hi Byte  
Byte 2 – Previous Time Lo Byte  
Byte 3 – New Time Hi Byte  
Byte 4 – New Time Lo Byte

**Event ID: 0x000E**

**Definition:** Function Change

**Description:** Written to the log when Module functions are changed (Wheel Compensation Enabled, Disabled, Allow only -1 count, and Allow reset after fault) See Table 6-6.

**Event Specific Bytes:** Byte 1 – Previous Bit Field  
Byte 2 – New Bit Field

**Event ID: 0x000F**

**Definition:** Input State Change

**Description:** Written to the log when the state of input 1 – input 6 changes for at least 250 milliseconds.

**Event Specific Bytes:** Byte 1 – Input That Changed  
Byte 2 – Current State of input

**Event ID: 0x0010**

**Definition:** Baseline Error

**Description:** Written to the log when a check of a Wheel Sensor's baselines fails test. Sensor baselines are checked at zone reset and after a fault.

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor Number  
Byte 3 – Baseline Fault Bit Field (See Table 6-5)

**Event ID: 0x0012**

**Definition:** No Sensors Configured In Zone

**Description:** Written to the log when a zone is reset and there are no sensors configured for that zone.

**Event Specific Bytes:** Byte 1 – Zone Number

**Event ID: 0x0014**

**Definition:** Count Down from Zero

**Description:** Written to the log when the total zone count decreases from zero to a negative count. This event is written after the corresponding zone shows occupied status. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the previous count in the corresponding Wheel Sensor (initial count before total zone count decreased from zero)

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x0015**

**Definition:** Count Up to Zero

**Description:** Written to the log when the total zone count increases from a negative number up to zero. This event is written to the log after the corresponding zone output shows unoccupied status. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the current count in the corresponding Wheel Sensor (The count that caused the total zone count to increase to zero).

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x0016**

**Definition:** Count Down Through Zero

**Description:** Written to the log when the total zone count decreases from a positive number to a negative number. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the current count in the corresponding Wheel Sensor (The count that caused the total zone count to decrease).

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x0017**

**Definition:** Count Up Through Zero

**Description:** Written to the log when the total zone count increases from a negative number to a positive number. Sensor Count Register will be recorded in event specific bytes 3 and 4. Sensor count will reflect the current count in the corresponding Wheel Sensor (The count that caused the zone count to increase).

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID

Byte 3 – Sensor Count Hi Byte  
Byte 4 – Sensor Count Lo Byte

**Event ID: 0x0030**

**Definition:** Wheel Tracking

**Description:** This event is written to the log when the total zone count returns to zero, a zone reset occurs, a fault occurs, or wheel compensation event occurs. This event does not conform to the standard event log format (See Table 6-7).

**Event ID: 0x8000**

**Definition:** Critical Fault (Loopback Mismatch)

**Description:** This event is written to the log when the loopback state of the four zone occupied/unoccupied outputs do not match the intended output.

**Event Specific Bytes:** Byte 1 – (0xF0 – Output, 0x0F – Loopback)

**Event ID: 0x8007**

**Definition:** Sensor Communication Data - Frame Error/Unresponsive Retries

**Description:** Written to the log when a frame error or unresponsive retry occurs and communication is reestablished, or if *number of frame errors + unresponsive retries = 20*.

**Event Specific Bytes:** Byte 1 – Zone Number  
Byte 2 – Sensor ID  
Byte 3 – Number of Frame Errors  
Byte 4 – Number of Unresponsive Retries

**Event ID: 0x8012**

**Definition:** Record Sensor Baselines

**Description:** This event records the baseline parameters of each Wheel Sensor. It is written to the log at zone reset and after a fault occurs. This Event does not conform to the standard event log format (See Table 6-7).

**Event ID: 0x8013**

**Definition:** Threshold Values Error

**Description:** This event occurs when the Positive Threshold Values of the Coils are not equal to 5 or if the Negative Threshold Values of the Coils do not equal 8.

**Event Specific Bytes:** Byte 1 – Coil #1 (+) Threshold  
Byte 2 – Coil #1 (-) Threshold  
Byte 3 – Coil #2 (+) Threshold  
Byte 4 – Coil #2 (-) Threshold

## 7.0 MMZ Module Programmer PC Software




Figure 7-0 Rail Programmer software

### 7.1 Zones Tab

Zones Tab is used to group Wheel Sensors into one of the four zones.

**All Wheel Sensor/Module ID numbers are programmed in decimal format.**

**Sensor ID** – The identification number of the Wheel Sensor. Sensor IDs are input in decimal format. Sensor IDs 0, 1, 2, 3 and 153 are reserved and cannot be used.

**Module ID** – The identification number of the MM4Z Module a given Wheel Sensor ID is connected. When programming a sensor that is attached to current Module, Module ID can be left blank or programmed to zero. Module IDs 0 and 255 are reserved and should not be used.

#### 7.1.1 Adding/Removing sensors to a Zone

- **Adding**

Clicking on any of the four Zone lists will enable it for editing.

The “Sensor ID” and “Module ID” textboxes are used to input ID number in decimal format.

The “Add” button is used to store ID number into selected zone lists.

- **Removing**

Selecting a non-blank line from any of the four Zone lists and using the “Remove” button, will remove it from the selected list.

Once information is added or removed from a zone list view, the corresponding “Write” button will change colors to red indicating a change has been made which has not yet been written to the Module.

### 7.1.2 Configuring sensor for “Count Down” direction

To configure a sensor for the count down direction, use a minus sign “ - ” in front of the Sensor ID number.

For example:

#	Sensor ID	Module ID	Auto Line
1	04		
2	-05		

**Figure 7-1 Zone List View Example**

Referring to line #1 and line #2 from Figure 7-1, Sensor ID 04 will add its count to the total Zone count, while Sensor ID 05 will subtract its count from the total Zone count.

### 7.1.3 Reading/Writing Zones

While Module is in Run Mode Wait Sequence (See Section 4.2.0), read / write zone operations using Function Code 0x10 are permitted.

While Module is in Run Mode Poll Sequence (See Section 4.2.1), only read operations are permitted.

## 7.2 Event Log Tab

From the event log tab, the full event log can be read from memory and exported to .xls (excel workbook) or tab delimited text file.

## 7.3 Monitor Tab

From the Monitoring Tab, zone counts, current state of inputs/outputs, currently occurring events, and wheel tracking can be monitored in real time.

Note: When monitoring currently occurring events; if more than one event happens at the same time, only one event will be displayed. To display a list of every event, the Event Log tab can be used.

## 7.4 Module Tab

From the Module Tab, Module parameters can be read and edited.




Figure 7-3 Module list tab


### 7.4.0 Searching Network for connected Modules

When using the Ethernet option, the search button must first be used to search the network for all Ethernet enabled Modules on the network. When using the Serial option, select the unit ID of the Module you would like to read/edit. If the unit ID of the Module is unknown, the universal unit ID (255) can be used.

**The MM4Z Module ships with default IP Address “192.168.1.8”, Default Gateway “192.168.1.1”, and 8 host bits**

**The default Network configuration can be reset in Firmware version 1.23 and above using the method outlined in Function 3 of section 1.2.1**

#### Searching Network:

a. The  **Search** button will scan your Network for all Ethernet enabled MM4Z Modules.

#### ● If the Scan Returned NO Results

If the scan of your Network returned no results and there is a properly powered up MM4Z Module on your network.



#### 7.4.0.0 Verify Ethernet Port Operation

Ensure the MM4Z Module's Ethernet Port LED1 is illuminated Solid Green or Solid Amber and the LED on your computers Ethernet Network Card is displaying a solid Green light. If no LED lights are illuminated or a Red LED is illuminated on your PC's network card, then no Ethernet link between your PC and the MM4Z module exists.

#### 7.4.0.1 Verify the correct Ethernet Network adapter is selected

If your PC has more than one enabled Ethernet adapter, it may be possible that the wrong Ethernet adapter is selected. By default, the PC software will use the first enabled adapter to appear in the PC's list of network adapters. (See Section 7.6.1 - Network Adapters)

#### 7.4.0.2 Verify/Edit the IP Configuration of your PC

It may be possible that your PC is broadcasting Ethernet communications on a different Gateway or Subnet mask than the MM4Z Module is listening.

This situation may arise when this is the first time configuring the MM4Z Module, or if you are moving a MM4Z Module from one network to another. This can be resolved by temporarily changing the IP configuration of your PC.


**Warning: Record any PC configurations before editing them.**

#### To Edit PC Network Configurations:


- Open the "Local Area Connection Status". This can be opened from the Control Panel on your Windows PC or by viewing your network connections.

- Click the "Properties" button to display the "Local Area Connection Properties".


- Scroll down and highlight "Internet Protocol (TCP/IP)", then click the "Properties" button to display "Internet Protocol (TCP/IP) Properties".



**Figure 7- 4 Local Area Connection Status**



**Figure 7- 5 Local Area Connection Properties**




**Figure 7- 6 Internet Protocol (TCP/IP) Properties**

- From the “Internet Protocol (TCP/IP) Properties, the IP configuration of the PC can be changed.

In this example, it is assumed that this is the first time changing the IP configuration of the MM4Z Module. The MM4Z Module ships with default IP Address 192.168.1.8. Default Gateway and Subnet mask are left un-configured.

To allow the PC to communicate with this Module, we will change the IP Address of the PC to a unique 192.168.1.x number. We will use IP Address 192.168.1.9.

Once the new IP Address is entered into the IP address field, the Subnet mask should auto fill based on the input IP. The last thing we will do is change the Default Gateway to something that includes the new IP Address, “192.168.1.1” in this example.

After we have changed the IP Address of our computer, the  **Search** can again be used to search for Ethernet enabled MM4Z Modules.

#### **7.4.0.3 Restore Default Network Configuration to Module**

See Section 1.2.1 Function 3

#### **7.4.1 Edit Device Details Tab**

From the Edit Device Details Tab, the network configuration, unit ID number, Wheel Compensation function, Wheel Compensation time, Rest functions, and Date/Time can be edited.

#### **7.4.2 Read Network Configuration Tab**

The Read Network Configuration Tab is used to read Ethernet configuration of the MM4Z Module through a RS485 connection. The Ethernet configuration can only be read immediately after Module power up before any zones are enabled.

### **7.5 Wheel Sensor Tab**

From the Wheel Sensor Tab, all Wheel Sensor parameters can be read / written via Ethernet or Serial communication.

#### **7.5.0 Port Type**

Two port options are available when using the Serial Option.

##### **a. 4 Pin**

Any of the Zone 1 – Zone 4 connectors are referred to as the 4 Pin connector type.

**b. RJ45**

The RJ45 connector is only available when the Ethernet option is not present. The RJ45 serial connector will be in place of the Ethernet connector.

**7.5.1 Auto-Detect**

Auto-Detect will scan for all connected Wheel Sensors and display them in the “list of Auto-Detected”

**7.5.2 Scan/Diagnose**

Scan/Diagnose function will scan for all connected Wheel Sensors. When a Wheel Sensor is found, its parameters will be read and a test performed before displaying.

**7.5.3 Read ID**

Read ID function will read a connected Wheel Sensor using universal sensor ID 0x99.

**7.5.4 Send ID**

Send ID function will write a new ID number to the desired Wheel Sensor. Send ID function requires a Sensor ID and New Sensor ID number.

**7.5.5 Read Coil**

Read Coil function will read the Threshold, Analog Values, Sensitivity, Baseline, and Count Register of the Wheel Sensor whose ID number is input into the Sensor ID textbox.

If the Monitor checkbox is selected, the Read Coil function will continuously poll Wheel Sensor parameters.

**7.5.6 Send Coil**

Send Coil function will write Threshold values to the Wheel Sensor whose ID number is input into the Sensor ID textbox.

## 7.6 Ethernet Configuration menu

Ethernet Configuration menu is located under the **Ethernet** → **Communication Setup** menu. Communication Setup menu is used for storing the IP addresses of all the Modules you wish to communicate with.

### 7.6.0 Module IPs Tab




Figure 7-7 Module IPs Tab

Clicking on the Module Addresses list will enable the text boxes for inputting the desired IP Addresses. After inputting the IP address and an optional descriptive name, the IP address can be added to the Module Addresses list using the “Add” button.

Note: when using this software to communicate with the Ethernet protocol, the Port number is fixed at 502.

### 7.6.1 Network Adapters Tab




Figure 7-8 Network Adapters Tab

Network Adapters tab will display all installed network adapters on your Windows system.

By default, the MM4Z PC software will select the first enabled Ethernet adapter in the Windows system's list of network adapters.

Selecting any of the enabled network adapters from the list then clicking the "Use Adapter" button, will select that adapter for all further Ethernet communication.

### 7.7 Selecting an IP Address for Communication

After inputting IP addresses using the Module IPs tab (See Section 7.6.0), the input IP addresses will be available in the collapsible IP list on the main program page.




Figure 7-9 Ethernet menu expanded

### 7.8 Serial menu

From the Serial menu, the COM Port, Port Type, and Upgrade Firmware options can be selected.

The Serial menu is only available when the Serial Protocol is selected.

#### 7.8.0 COM Ports

List of all available COM Ports


#### 7.8.2 Upgrade Firmware


#### To upgrade the MM4Z Module Firmware

1. Attach MM4Z-06CB cable (See Diagram D.1) to TB4
2. Power up Module with Pin 8 of Terminal Block 1 held HIGH to enter Programming Mode (See Section 4.2)
3. Use the **Serial** → **COM Port** menu of the MM4Z PC software to select COM Port MM4Z-06CB cable is connected to.
4. Upgrade Firmware: Click **Serial** → **Upgrade Firmware**. Navigate to the \*.ifrm upgrade file. The Module upgrade will begin immediately.


5. Once Firmware Upgrade completes successfully, Detach Programming cable and Power up module with Pin 8 of Terminal Block 1 held LOW or left floating to enter Run Mode (See Section 4.2).

**Diagrams**




A Corrected pin numbers, added 8-2-10 JAS wire function names.		 LOCKPORT, NY.				
		NO. MM4Z-06CB TITLE MM4Z Programming Cable				
DESCRIPTION	DATE	APPVD.	ERS DRAWN	7-26-10 DATE	JAS CHKD.	JAS APPVD.
REVISIONS						

**D.1 MM4Z-06CB Programming Cable**



**D.2 RS485 Communication Cable**





### D.3 Wheel Compensation Flow Diagram

## **ANNEX A. Revision History**

### **A.1 Revision 1.0 Initial Revision**

### **A.2 Revision 1.1 Updated procedure to change Ethernet configurations using the MM4Z Programmer software**

### **A.3 Revision 1.2 Updated MM4Z-06CB Programming Cable Drawing**

### **A.4 Revision 1.2.1 Update Event Code 0x0010, 0x0014, and 0x0015**

### **A.5 Revision 1.2.2 Updated photos for new PC software General reformatting**

### **A.6 Revision 1.3 Expanded explanation of events Added Wheel Compensation flow diagram RS485 Communication cable diagram**

### **A.7 Revision 1.4 Definition/example for Function Code 0x05 and 0x06**

### **A.8 Revision 1.5 Definitions for Function Code 0x11**